



HAMPTON KITCHEN PRODUCT DETAILS AND CARE INFORMATION



PRODUCT DETAILS

The Hampton door is manufactured from four tulipwood sides and a medium density fibreboard centre piece, two very stable materials used to create long lasting doors and strong frames.

A design feature of the Hampton door is its seamless frame. The door manufacturers achieve this by joining the four individual sides without the traditional decorative v-groove in the corner joint.

The door is manufactured from Kiln Dried and conditioned to be suitable for use in normal domestic environments and conditions. It should be noted that under varying conditions of temperature and humidity, solid wood products, will naturally expand and contract which may result in hairline cracks of the paint finish at the construction joints. This is a natural feature of solid wood materials and cannot be considered a defect of the product.

CARE INSTRUCTIONS:

- As with all kitchen furniture the most common problems found occur as a result of excessive or prolonged exposure to heat and/or moisture. Always ensure that water is not left pooled around sink area.
- Always wipe off excess moisture and be careful with extreme heat sources, such as kettles, ovens and toasters. It is recommended that kettles and toasters are not placed directly under wall units when they are in use as they generate a higher level of heat and moisture that is often appreciated and can damage the kitchen furniture.
- Don't place appliances that create steam (e.g. Steamer, coffee maker or kettle) underneath the cabinets to avoid the steam flowing up against the underside of the cabinets or doors.
- If using glass cleaner to clean glass doors we recommend spraying a small amount of the glass cleaner on to a lint free cloth or paper towel, then wipe glass.
- Don't open the door of the dishwasher during the cycle or immediately after the cycle has finished as the exposure to heat and high humidity increases the risk that the door may absorb moisture and swell.

CLEANING ADVISE FOR ALL KITCHEN DOOR TYPES

- Do not use wax-furniture polish, abrasive or aggressive cleaners, bleach or other chlorine based cleaner, dilutes acetone, alcohol solvent or similar products on the door as this will damage the surface. Additionally, wax and polishes leave a residue build up that is difficult to remove.
- Only use a 5% soap, 95% water solution, wiping with a damp (not wet) cloth, finally drying with a soft clean cloth only.
- Ensure all cooking splashes are wiped immediately with a damp cloth
- Dust with a soft cloth only
- Never use any abrasive pads or abrasive cleaners on the furniture. Spills and condensation on the panels should be cleaned and dried immediately.